MATERIALS MATTER

MARK MICHAUD REM TECHNICAL FELLOW • • REM SURFACE ENGINEERING



Roughness measurement tips: Calibration, the razor blade test

If a problem is found with a contact stylus profilometer during routine check with a Rubert-Song specimen, do a little troubleshooting before sending it off for calibration and recertification.

n my previous column in Materials Matter, I reviewed the use of the "Scratch Pad" for the overall checking of the contact stylus profilometer's calibration. Use of a Rubert-Song D-type precision reference specimen on the shop floor is the preferred specimen for use in checking a precision gear tooth flank. The column noted that full calibration of a profilometer is a lengthy, complex, and costly process involving all three major sub-components of the profilometer: the stylus, the drive head, and the controller-processor unit. I said I would go into detail in this column on the full calibration process. So, here goes:

FULL CALIBRATION

The contact stylus profilometer is similar to a modern car. Most things under the hood are analyzed and adjusted by computers designed specifically for that purpose. These adjustments are normally done at a professional auto service center. Things such as changing spark plugs, oil filters, or even the oil, now require specialized tools. Little is left for car owners to service or adjust on their own.

The necessary specialized Precision Reference Specimens for calibration of a contact stylus profilometer are defined in ISO -5436-1 (1996) or ASME B 64.1-2002. These are the A-C type specimens. Typically made out of silicon glass, they are quite expensive and somewhat difficult to use. A-type specimens are for checking the vertical magnification of the instrument. B-type specimens are for checking the condition of the stylus tip. C-type specimens are for checking the readout of the various roughness parameters. Multiple specimens of each type are needed, depending on the targeted engineered surface roughness range, and still more if different tip radii are incorporated with the unit. Proper use of these specimens will indicate whether the profilometer is within calibration. But, at the end of the day, further specialized software, electronics and/or mechanical equipment (in the case of the drive head) are needed to make calibration adjustments to the profilometer. As I said, this is a complex, lengthy, and costly process.

CALIBRATION PROCESS

Fortunately, I have a simplified process to follow. Step one: Pack the instrument carefully in a damage-resistant container. Shop floor profilometers are small, compact instruments that will easily fit into a double-walled box. Step two: Ship the instrument to an independent service provider qualified to calibrate and recertify the profilometer. Step three: Return the instrument to shop-floor use once it is recertified.



A profilometer used for measuring surface texture. (Courtesy: Shutterstock)

Types and names

Surface texture standards are material measures used for calibrating the metrological characteristics of surface texture measuring instruments using the profile method (ISO 3274).

Name	Туре	Application	Suitability
Depth measurement standard	A	Calibrating the vertical profile component	Groove depth Pt
Tip condition measurement standard	В	Monitoring the condition of the stylus tip	Stylus tip radius
Sine-wave profile standard / Spacing measurements standards	С	Calibration of vertical and horizontal profile components independent from geometry of stylus tip Constancy of traversing	Ra, Rz RSm Ar
		movement. Determining the sensitivity of the signal transmission chain	
Grinded metallic roughness measurement standard	D	Dynamic calibration of the measuring station	Ra, Rz, . Rk, Rpk, Rvk, Stylus tip radius
Precision prism	E	Calibrating the profile coordinate system of the instrument	
Ball or hemisphere	E	Determining the residual error Testing the profile coordinate system of the instrument Error detecting	
Optical flat		Vibration measurement Datum plane mapping	Noise Rz0 Guiding deviation

Standards according to ISO 5436 with calibration certificates document the traceability to national standards, which represent the units of measurement according to the International System of Units (SI). The smaller the uncertainty of measurement of a standard, the larger the tolerance range left for production.

Figure 1: Mahr certification protocol (Courtesy: Mahr GmbH).

Unless a routine check using the Rubert-Song specimen shows a significant problem that cannot be easily resolved, an independent calibration and recertification of an instrument are not needed more than once a year, or even once every several years.



Figure 2: SEM photo of a tip in good condition. (Courtesy: REM Surface Engineering)



Figure 3: SEM photo of a damaged tip. (Courtesy: REM Surface Engineering)

Figure 1 is a typical specimen and certification outline provided by Mahr. Taylor Hobson and Hommel, all manufacturers of quality shop floor profilometers, can provide similar services. Probably the preferred service provider is the original instrument manufacturer.

Unless a routine check using the Rubert-Song specimen shows a significant problem that cannot be easily resolved, an independent calibration and recertification of an instrument are not needed more than once a year, or even once every several years. The end user's quality manual should specify the instrument recertification process and frequency.

ROUTINE CHECKS

However, what if a routine Rubert-Song check indicates a problem? Do you immediately send the profilometer off to the independent calibration service provider? The answer is no, not yet. Remember that in my earlier articles, I explained the stylus is the component most likely to be a problem. Diamond tip styli get dirty, wear down, or



Figure 4: Diagram of a Song razor blade specimen. (ASME B 46.1)



Figure 5: Razor blade and holder.

break. I recommend having spare styli for these reasons. Always look at the stylus to see if it is the source of the problem before sending out a profilometer for independent servicing.

To check a stylus, first, look at the tip under magnification. A scanning electron microscope is great if you have one. A SEM can reveal details of a damaged tip. Figure 2 is an SEM photo of a tip in good condition. Figure 3 is an SEM photo of a damaged tip.

But any close-up examination will work to reveal dirt or a broken tip. If dirt is present, clean the tip with a suitable solvent (acetone) and then retest the unit using the Rubert-Song calibration specimen. If an examination shows the tip is broken, replace the tip with a new one. Tips cannot be rebuilt.

WORN TIP

But what if the tip is just worn? Examination under a microscope will not easily reveal this condition. A worn 2- or 5-micron tip will not look much different from a new tip. Nevertheless, a worn tip can lead to measurements appearing to show a smoother-than-actual surface. If the specified roughness is Ra < 0.2 micron, this could result in a significant gear performance issue such as scuffing.

If microscopic examination does not show dirt or a broken tip, do you send the profilometer off to be recalibrated? Not yet! There is a simple method to check the tip radius that does not involve the use of a specialized, costly calibration specimen. Credited to J. F. Song, it is called a "razor blade" check. This stylus checking method is



Figure 6: Razor blade test showing a satisfactory 2-micron tip radius. (Courtesy: REM Surface Engineering)

designated as the B-3 type specimen in above referenced ISO and ASME Standards.

What this method is based on is a typical hardware store razor blade. Simply hold a blade in a very smooth surfaced fixture with the edge just projecting above the smooth block surface. The diamond tip stylus condition may be accurately measured by tracing it across the edge of the blade. See Figure 4 for a representation of a Song razor blade set-up.

A new razor blade will typically have an edge radius of less than 0.1 micron. By traversing the stylus across the slightly protruding razor's edge, the tip's radius can be measured. If r_1 is the tip radius and r_2 is the razor blade radius, the measured radius $r = r_1 + r_2$. In addition, since the razor blade's edge is much smaller than a 2 or 5 stylus tip, the measured radius is essentially equal to the tip radius itself. A worn tip or a broken tip will be easily revealed in this stylus checking method. Figure 5 is a photograph of my razor blade specimen and holder. It was fabricated locally.

Using the specimen in Figure 5, the trace is taken where the blade is just projecting above the surface of the block. This avoids problems



Figure 7: Razor blade test showing a 2-micron tip that has worn to ~3-micron. (Courtesy: REM Surface Engineering)

with a stylus' skid affecting the measurement. By importing the profilometer's traced measurements as an ASCII file, the data can be incorporated into a spreadsheet graph showing the radius of the tip.

Figure 6 is a razor blade measurement of a good 2-micron tip. Figure 7 shows the measurement of a 2-micron tip that shows no damage, but worn to a radius of \sim 3 micron. This tip was taken out of service as it could result in inaccurately smooth results on low *Ra* engineered surfaces such as a tooth flank.

CONCLUSION

It is recommended that a profilometer not be sent out for calibration and recertification immediately when a problem is revealed during routine check with a Rubert-Song specimen. First, the stylus tip should be examined for dirt, damage, and/or wear. If clean and undamaged, the tip should be checked for wear using a Song razor blade test. If the tip is worn significantly, it should be replaced. If the tip is not worn, then it is recommended the profilometer be sent out to an independent services provider for calibration and recertification.

ABOUT THE AUTHOR

Mark Michaud, REM Technical Fellow of REM Surface Engineering, is the inventor and pioneer of REM Surface Engineerings's chemically accelerated finishing technology. He has authored numerous patents and technical papers and served a term on the AGMA Board of Directors. He continues to serve as vice chair of the AGMA Aerospace Committee, as a member of the AGMA Wind Turbine Committee and as a shadow delegate on the ISO 61400-4 Wind Turbine Committee. He can be reached at mmichaud@remchem.com.